

European Network of Transmission System Operators for Electricity

GRID DISTURBANCE PROFILE SPECIFICATION

2023-05-10

APPROVED DOCUMENT VERSION 1.0

ENTSO-E | Rue de Spa, 8 | 1000 Brussels | info@entsoe.eu | www.entsoe.eu | @entso_e



Copyright notice:

2 Copyright © ENTSO-E. All Rights Reserved.

This document and its whole translations may be copied and furnished to others, and derivative works that comment on or otherwise explain it or assist in its implementation may be prepared, copied, published and distributed, in whole or in part, without restriction of any kind, provided that the above copyright notice and this paragraph are included on all such copies and derivative works. However, this document itself may not be modified in any way, except for literal and whole translation into languages other than English and under all circumstances, the copyright notice or references to ENTSO-E may not be removed.

10 This document and the information contained herein is provided on an "as is" basis.

11 ENTSO-E DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT 12 LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT 13 INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR 14 FITNESS FOR A PARTICULAR PURPOSE.

15 This document is maintained by the ENTSO-E CIM WG. Comments or remarks are to be 16 provided at <u>cim@entsoe.eu</u>

17 NOTE CONCERNING WORDING USED IN THIS DOCUMENT

- 18 The force of the following words is modified by the requirement level of the document in which 19 they are used.
- SHALL: This word, or the terms "REQUIRED" or "MUST", means that the definition is an absolute requirement of the specification.
- SHALL NOT: This phrase, or the phrase "MUST NOT", means that the definition is an absolute prohibition of the specification.
- SHOULD: This word, or the adjective "RECOMMENDED", means that there may exist valid reasons in particular circumstances to ignore a particular item, but the full implications must be understood and carefully weighed before choosing a different course.
- SHOULD NOT: This phrase, or the phrase "NOT RECOMMENDED", means that there may exist valid reasons in particular circumstances when the particular behaviour is acceptable or even useful, but the full implications should be understood and the case carefully weighed before implementing any behaviour described with this label.
- MAY: This word, or the adjective "OPTIONAL", means that an item is truly optional.

32



Revision History

Version	Release	Date	Paragraph	Comments
1	0	2023-02-02		ICTC approved
1	0	2023-05-10		It was noticed that manuallyAfterRepair value was missing in the AutoReclosingKind enumeration. This new release includes the missing value manuallyAfterRepair in the model.



CONTENTS

35	Сор	Copyright notice:						
36	Rev	ision Hist	tory	3				
37	CON	NTENTS.	· · ·	4				
38	1	Introduc	ction	7				
39	2	Applicat	tion profile specification	7				
40		2.1	Version information					
41		2.2	Constraints naming convention					
42		2.3	Profile constraints					
43		2.4	Metadata					
44		2.1	2.4.1 Constraints					
45			2.4.2 Reference metadata					
46	3	Detailed	Profile Specification					
47	-	3.1	General					
48		3.2	(abstract) BaseVoltage					
49		3.3	CoordinateSystem					
50		3.4	(abstract) Document					
51		3.5	(Description) Equipment root class					
52		3.6	Fault					
53		3.7	(NC) FaultCause root class					
54		3.8	FaultCauseType					
55		3.9	(NC) FaultOutage root class					
56		3.10	(NC) GridDisturbance					
57		3.11	(abstract) IdentifiedObject root class					
58		3.12	(NC) Interruption	.17				
59		3.13	Location					
60		3.14	(abstract) Outage	.18				
61		3.15	PositionPoint root class	.18				
62		3.16	(abstract,NC) SystemOperator root class	.19				
63		3.17	UnplannedOutage	.19				
64		3.18	(NC) AutoReclosingKind enumeration	.20				
65		3.19	(NC) CertaintyLevelKind enumeration	.21				
66		3.20	(NC) FaultCategoryKind enumeration	.21				
67		3.21	(NC) FaultKind enumeration	.22				
68		3.22	PhaseConnectedFaultKind enumeration	.22				
69		3.23	PhaseCode enumeration	.23				
70		3.24	(NC) SystemUnitKind enumeration	.24				
71		3.25	(NC) TripKind enumeration	.25				
72		3.26	UnitMultiplier enumeration	.25				
73		3.27	UnitSymbol enumeration	.26				
74		3.28	ActivePower datatype	.26				
75		3.29	RealEnergy datatype	.26				
76		3.30	Boolean primitive					
77		3.31	DateTime primitive	.27				



3.32	Duration primitive	27
3.33	Integer primitive	27
3.34	Float primitive	27
3.35	String primitive	27
List of figu	Ires	
Figure 1 –	Class diagram GridDisturbanceProfile::GridDisturbance	11
List of tab	les	
Table 1 – A	Attributes of GridDisturbanceProfile::BaseVoltage	11
Table 2 – A	Attributes of GridDisturbanceProfile::CoordinateSystem	11
Table 3 – A	Attributes of GridDisturbanceProfile::Document	12
Table 4 – A	Association ends of GridDisturbanceProfile::Equipment with other classes	12
Table 5 – A	Attributes of GridDisturbanceProfile::Fault	12
Table 6 – A	Association ends of GridDisturbanceProfile::Fault with other classes	14
Table 7 – A	Attributes of GridDisturbanceProfile::FaultCause	15
Table 8 – A	Association ends of GridDisturbanceProfile::FaultCause with other classes	15
Table 9 – A	Attributes of GridDisturbanceProfile::FaultCauseType	15
Table 10 –	Attributes of GridDisturbanceProfile::FaultOutage	16
Table 11 –	Association ends of GridDisturbanceProfile::FaultOutage with other classes	16
Table 12 –	Attributes of GridDisturbanceProfile::GridDisturbance	16
Table 13 –	Attributes of GridDisturbanceProfile::IdentifiedObject	16
Table 14 –	Attributes of GridDisturbanceProfile::Interruption	17
Table 15 –	Association ends of GridDisturbanceProfile::Interruption with other classes	17
Table 16 –	Attributes of GridDisturbanceProfile::Location	18
Table 17 –	Association ends of GridDisturbanceProfile::Location with other classes	18
Table 18 –	Attributes of GridDisturbanceProfile::Outage	18
Table 19 –	Association ends of GridDisturbanceProfile::Outage with other classes	18
Table 20 –	Attributes of GridDisturbanceProfile::PositionPoint	19
		19
		20
Table 25 –	Literals of GridDisturbanceProfile::CertaintyLevelKind	21
Table 28 –	Literals of GridDisturbanceProfile::PhaseConnectedFaultKind	22
Table 29 –	Literals of GridDisturbanceProfile::PhaseCode	23
	3.33 3.34 3.35 List of figu Figure 1 – List of tab Table 1 – A Table 2 – A Table 2 – A Table 3 – A Table 4 – A Table 5 – A Table 6 – A Table 7 – A Table 7 – A Table 7 – A Table 10 – Table 10 – Table 11 – Table 11 – Table 12 – Table 13 – Table 13 – Table 14 – Table 15 – Table 15 – Table 16 – Table 16 – Table 17 – Table 17 – Table 18 – Table 20 –	3.33Integer primitive3.34Float primitive



118	Table 30 – Literals of GridDisturbanceProfile::SystemUnitKind	24
119	Table 31 – Literals of GridDisturbanceProfile::TripKind	25
120	Table 32 – Literals of GridDisturbanceProfile::UnitMultiplier	25
121	Table 33 – Literals of GridDisturbanceProfile::UnitSymbol	26
122	Table 34 – Attributes of GridDisturbanceProfile::ActivePower	26
123	Table 35 – Attributes of GridDisturbanceProfile::RealEnergy	27
404		

- Page 6 of 27 -



125 **1** Introduction

126 The grid disturbance profile is a profile to exchange a list of already occurred grid disturbances, 127 faults, outages and interruptions. A grid disturbance is defined as "Automatic, unintended, or

manual undeferrable switching of breakers as a result of faults in the power grid".

The grid disturbances are input data that describe incidents in the power grid. This input data
 is used for statistical purposes and for Probabilistic Risk Assessment (PRA) pursuant to CSAM
 Article 44.

132 **2** Application profile specification

133 2.1 Version information

134 The content is generated from UML model file CIM100_CGMES31v01_501-135 20v02_NC22v95_MM10v01.eap.

- 136 This edition is based on the IEC 61970 UML version 'IEC61970CIM17v40', dated '2020-08-24'.
- 137 Title: Grid Disturbance vocabulary
- 138 Keyword: GD
- Description: This vocabulary is describing the grid disturbance profile.
- 140 Version IRI: http://entsoe.eu/ns/CIM/GridDisturbance-EU/1.0
- 141 Version info: 1.0.0
- 142 Prior version:
- 143
 Conforms to: urn:iso:std:iec:61970-600-2:ed-1|urn:iso:std:iec:61970-301:ed

 144
 7:amd1|file://iec61970cim17v40_iec61968cim13v13a_iec62325cim03v17a.eap|urn:iso:

 145
 std:iec:61970-401:draft:ed-1|urn:iso:std:iec:61970-501:draft:ed-2|file://CGMES

 146
 30v25_501-20v01.eap
- 147 Identifier: urn:uuid:81c488d7-a09f-49ef-a3cd-3bb19a1d6f16
- 148

149 2.2 Constraints naming convention

150 The naming of the rules shall not be used for machine processing. The rule names are just a 151 string. The naming convention of the constraints is as follows.

- 152 "{rule.Type}:{rule.Standard}:{rule.Profile}:{rule.Property}:{rule.Name}"
- 153 where
- 154 rule.Type: C for constraint; R for requirement

rule.Standard: the number of the standard e.g. 301 for 61970-301, 456 for 61970-456, 13 for

- 156 61968-13. 61970-600 specific constraints refer to 600 although they are related to one or
- 157 combination of the 61970-450 series profiles. For CSA profiles, CSA is used.
- rule.Profile: the abbreviation of the profile, e.g. TP for Topology profile. If set to "ALL" the constraint is applicable to all IEC 61970-600 profiles.
- 160 rule.Property: for UML classes, the name of the class, for attributes and associations, the name
- of the class and attribute or association end, e.g. EnergyConsumer, IdentifiedObject.name, etc.
- 162 If set to "NA" the property is not applicable to a specific UML element.



- 163 rule.Name: the name of the rule. It is unique for the same property.
- 164 Example: C:600:ALL:IdentifiedObject.name:stringLength

166

167 2.3 Profile constraints

168 This clause defines requirements and constraints that shall be fulfilled by applications that 169 conform to this document.

- This document is the master for rules and constraints tagged "CSA". For the sake of selfcontainment, the list below also includes a copy of the relevant rules from IEC 61970-452, tagged "452".
- C:452:ALL:NA:datatypes
- According to 61970-501, datatypes are not exchanged in the instance data. The UnitMultiplier is 1 in cases none value is specified in the profile.
- R:452:ALL:NA:exchange
- 177 Optional and required attributes and associations must be imported and exported if they 178 are in the model file prior to import.
- R:452:ALL:NA:exchange1
- If an optional attribute does not exist in the imported file, it does not have to be exported
 in case exactly the same data set is exported, i.e. the tool is not obliged to automatically
 provide this attribute. If the export is resulting from an action by the user performed after
 the import, e.g. data processing or model update the export can contain optional
 attributes.
- 185 R:452:ALL:NA:exchange2

186 In most of the profiles the selection of optional and required attributes is made so as to 187 ensure a minimum set of required attributes without which the exchange does not fulfil 188 its basic purpose. Business processes governing different exchanges can require 189 mandatory exchange of certain optional attributes or associations. Optional and required attributes and associations shall therefore be supported by applications which claim 190 191 conformance with certain functionalities of the IEC 61970-452. This provides flexibility for the business processes to adapt to different business requirements and base the 192 exchanges on IEC 61970-452 compliant applications. 193

• R:452:ALL:NA:exchange3

An exporter may, at his or her discretion, produce a serialization containing additional
class data described by the CIM Schema but not required by this document provided
these data adhere to the conventions established in Clause 5.

198 • R:452:ALL:NA:exchange4

From the standpoint of the model import used by a data recipient, the document describes a subset of the CIM that importing software shall be able to interpret in order to import exported models. Data providers are free to exceed the minimum requirements described herein as long as their resulting data files are compliant with the CIM Schema and the conventions established in Clause 5. The document, therefore, describes additional classes and class data that, although not required, exporters will, in all



likelihood, choose to include in their data files. The additional classes and data are
 labelled as required (cardinality 1..1) or as optional (cardinality 0..1) to distinguish them
 from their required counterparts. Please note, however, that data importers could
 potentially receive data containing instances of any and all classes described by the
 CIM Schema.

• R:452:ALL:NA:cardinality

The cardinality defined in the CIM model shall be followed, unless a more restrictive cardinality is explicitly defined in this document. For instance, the cardinality on the association between VoltageLevel and BaseVoltage indicates that a VoltageLevel shall be associated with one and only one BaseVoltage, but a BaseVoltage can be associated with zero to many VoltageLevels.

• R:452:ALL:NA:associations

Associations between classes referenced in this document and classes not referenced here are not required regardless of cardinality.

• R:452:ALL:IdentifiedObject.name:rule

The attribute "name" inherited by many classes from the abstract class IdentifiedObject is not required to be unique. It must be a human readable identifier without additional embedded information that would need to be parsed. The attribute is used for purposes such as User Interface and data exchange debugging. The MRID defined in the data exchange format is the only unique and persistent identifier used for this data exchange. The attribute IdentifiedObject.name is, however, always required for CoreEquipment profile and Short Circuit profile.

• R:452:ALL:IdentifiedObject.description:rule

The attribute "description" inherited by many classes from the abstract class ldentifiedObject must contain human readable text without additional embedded information that would need to be parsed.

• R:452:ALL:NA:uniqueIdentifier

All IdentifiedObject-s shall have a persistent and globally unique identifier (Master Resource Identifier - mRID).

• R:452:ALL:NA:unitMultiplier

For exchange of attributes defined using CIM Data Types (ActivePower, Susceptance, etc.) a unit multiplier of 1 is used if the UnitMultiplier specified in this document is "none".

- C:452:ALL:IdentifiedObject.name:stringLength
- 238 The string IdentifiedObject.name has a maximum of 128 characters.
- C:452:ALL:IdentifiedObject.description:stringLength
- 240 The string IdentifiedObject.description is maximum 256 characters.
- C:452:ALL:NA:float

An attribute that is defined as float (e.g. has a type Float or a type which is a Datatype with .value attribute of type Float) shall support ISO/IEC 60559:2020 for floating-point arithmetic using single precision floating point. A single precision float supports 7 significant digits where the significant digits are described as an integer, or a decimal



246number with 6 decimal digits. Two float values are equal when the significant with 7247digits are identical, e.g. 1234567 is equal 1.234567E6 and so are 1.2345678 and2481.234567E0.

- C:13:GL:CoordinateSystem.crsUrn:epsg
- 250 CoordinateSystem.crsUrn: If not specified elsewhere, the CoordinateSystem.crsUrn 251 uses WGS84 (latitude, longitude), i.e. urn:ogc:def:crs:EPSG::4326.
- C:13:GL:PositionPoint:coordinates

In order to support various coordinate systems, position attributes are defined as
 strings. It is up to the implementation to ensure to correctly parse coordinate positions
 as defined by the coordinate system type.

256

257 **2.4 Metadata**

ENTSO-E agreed to extend the header and metadata definitions by IEC 61970-552 Ed2. This new header definitions rely on W3C recommendations which are used worldwide and are positively recognised by the European Commission. The new definitions of the header mainly use Provenance ontology (PROV-O), Time Ontology and Data Catalog Vocabulary (DCAT). The global new header applicable for this profile is included in the metadata and document header specification document.

The header vocabulary contains all attributes defined in IEC 61970-552. This is done only for the purpose of having one vocabulary for header and to ensure transition for data exchanges that are using IEC 61970-552:2016 header. This profile does not use IEC 61970-552:2016 header attributes and relies only on the extended attributes.

268 2.4.1 Constraints

- The identification of the constraints related to the metadata follows the same convention for naming of the constraints as for profile constraints.
- R:CSA:ALL:wasAttributedTo:usage
- 272 The prov:wasAttributedTo should normally be the "X" EIC code of the actor (prov:Agent).
- 273

274 2.4.2 Reference metadata

275 The header defined for this profile requires availability of a set of reference metadata. For 276 instance, the attribute prov:wasGeneratedBy requires a reference to an activity which produced the model or the related process. The activities are defined as reference metadata and their 277 278 identifiers are referenced from the header to enable the receiving entity to retrieve the "static" (reference) information that it is not modified frequently. This approach imposes a requirement 279 that both the sending entity and the receiving entity have access to a unique version of the 280 reference metadata. Therefore, each business process shall define which reference metadata 281 282 is used and where it is located.

283 **3 Detailed Profile Specification**

284 3.1 General

285 This package contains the grid disturbance profile.






Figure 1 – Class diagram GridDisturbanceProfile::GridDisturbance

288 Figure 1: The diagram shows grid disturbance related classes.

289 3.2 (abstract) BaseVoltage

- 290 Inheritance path = <u>IdentifiedObject</u>
- 291 Defines a system base voltage which is referenced.
- 292 Table 1 shows all attributes of BaseVoltage.
- 293

Table 1 – Attributes of GridDisturbanceProfile::BaseVoltage

name	mult	type	description
description	01	<u>String</u>	inherited from: IdentifiedObject
mRID	11	<u>String</u>	inherited from: IdentifiedObject
name	01	<u>String</u>	inherited from: IdentifiedObject

294

295 3.3 CoordinateSystem

- 296 Inheritance path = <u>IdentifiedObject</u>
- 297 Coordinate reference system.

298 Table 2 shows all attributes of CoordinateSystem.

299

Table 2 – Attributes of GridDisturbanceProfile::CoordinateSystem

name	mult	type	description
crsUrn	11	String	A Uniform Resource Name (URN) for the coordinate reference system (crs) used to define 'Location.PositionPoints'.
			An example would be the European Petroleum Survey Group (EPSG) code for a coordinate reference system, defined in URN under the Open Geospatial Consortium (OGC) namespace as: urn:ogc:def:crs:EPSG::XXXX, where XXXX is an EPSG code (a full list of codes can be found at the EPSG Registry web site http://www.epsg- registry.org/). To define the coordinate system



name	mult	type	description
			as being WGS84 (latitude, longitude) using an EPSG OGC, this attribute would be urn:ogc:def:crs:EPSG::4236.
			A profile should limit this code to a set of allowed URNs agreed to by all sending and receiving parties.
description	01	<u>String</u>	inherited from: IdentifiedObject
mRID	11	<u>String</u>	inherited from: IdentifiedObject
name	01	<u>String</u>	inherited from: IdentifiedObject

301 3.4 (abstract) Document

302 Inheritance path = <u>IdentifiedObject</u>

- 303 Parent class for different groupings of information collected and managed as a part of a 304 business process. It will frequently contain references to other objects, such as assets, people
- 305 and power system resources.
- 306 Table 3 shows all attributes of Document.

307

Table 3 – Attributes of GridDisturbanceProfile::Document

name	mult	type	description
description	01	<u>String</u>	inherited from: IdentifiedObject
mRID	11	<u>String</u>	inherited from: IdentifiedObject
name	01	<u>String</u>	inherited from: IdentifiedObject

308

309 3.5 (Description) Equipment root class

- 310 The parts of a power system that are physical devices, electronic or mechanical.
- 311 Table 4 shows all association ends of Equipment with other classes.

312 Table 4 – Association ends of GridDisturbanceProfile::Equipment with other classes

mult from	name	mult to	type	description
1*	UnplannedOutage	01	<u>UnplannedOutage</u>	(NC) The outage this tripped breaker is involved with.

313

314 3.6 Fault

315 Inheritance path = <u>IdentifiedObject</u>

- 316 Abnormal condition causing current flow through conducting equipment, such as caused by
- 317 equipment failure or short circuits from objects not typically modelled (for example, a tree falling

318 on a line).

319 Table 5 shows all attributes of Fault.

320

Table 5 – Attributes of GridDisturbanceProfile::Fault

name mult		type	description
kind	01	<u>PhaseConnectedFaultKi</u> <u>nd</u>	The kind of phase fault.
phases	01	PhaseCode	The phases participating in the fault. The fault connections into these phases are further specified by the type of fault.
occurredDateTime	11	<u>DateTime</u>	The date and time at which the fault occurred.
duration	11	<u>Duration</u>	(NC) The duration of the fault.



name	mult	type	description
repairTime	01	Duration	(NC) Time from when repair commences, including necessary troubleshooting, until the unit's function(s) has (have) been resumed and the unit is ready for operation. Note 1: repair time is registered only for
			permanent faults and does not include administrative delays (voluntary waiting time). However, any preparations necessary to carry out repairs, for example the collection or ordering of spare parts, waiting for spare parts or transport, are included in the repair time.
			Note 2: the repair time is zero if a fault is left unrepaired deliberately.
			Note 3: this definition differs from the IEC 192- 07-19 definition by also including the preparation time necessary to carry out the repairs mentioned in note 1.
sequenceNumber	11	Integer	(NC) A chronological serial number indicating the order of the faults related to the grid disturbance.
			Primary faults have fault ID "1", and secondary/latent faults have fault ID "2" or more.
category	11	FaultCategoryKind	(NC) The fault category.
faultKind	11	FaultKind	 (NC) One fault can consist of several fault types. If a fault consists of several fault types, the most significant fault type is used. In case of developing faults, that is in faults changing from one type to another, the final type is given.
isDirectlyEarthed	11	Boolean	(NC) Whether the power system is directly earthed (true) or compensated (false).
			Usually optional for faults on units with reactive compensation with voltages lower than 100 kV.
isIntermittent	11	Boolean	(NC) The kind of occurrence of the fault. It is either intermittent (true) or non-intermittent (false).
			An intermittent fault is a recurring fault in the same unit and in the same place and for the same reason which repeats itself before it becomes necessary to carry out any repairs or eliminate the cause [8].
			A non-intermittent fault occurs only once.
			Note 1: a fault which repeats itself after an inspection, which did not result in the fault being pinpointed or repaired, is not considered an intermittent fault. A fault like this is considered as the beginning of a grid disturbance every time the fault occurs.
			Note 2: one example of an intermittent fault is galloping lines.
			Note 3: when deciding whether a fault is intermittent or not, one should consider more of the cause, location and consequence of the fault and not on the time between the faults. An intermittent fault is counted as one fault. However, all individual caused outages are connected to this fault.
			Note 4: there is no standard for the required timespan between intermittent faults. Some system operators use 2 hours.



name	mult	type	description
isPermanent	11	Boolean	(NC) Whether the fault is a permanent (true) or a temporary (false) fault.
			A permanent fault is a fault that will remain unless it is removed by some intervention.
			Note 1 to entry: The "intervention" may be modification or maintenance.
			Note 2: a permanent fault requires repair or adjustment before the unit is ready for operation. For example, the resetting of computers is considered as repair work and a switch in the wrong position is considered as a permanent fault. Signal acknowledgement is not considered as repair work.
			Note 3: the duration of the disconnection is irrelevant when determining if a fault is permanent or not.
			A temporary fault is a fault where the unit or component is undamaged and is restored to service by switching operations without repair but possibly with on-site inspection.
			Note 1: a temporary fault does not require measures other than the reconnection of circuit breakers, replacement of fuses or signal acknowledgement.
			Note 2: the duration of the disconnection is irrelevant when determining if a fault is temporary or not. If, for example, a fault results in long-term disconnection and (on-site) inspection cannot pinpoint its source, the fault is considered to be temporary as no repairs are carried out.
description	01	<u>String</u>	inherited from: IdentifiedObject
mRID	11	<u>String</u>	inherited from: IdentifiedObject
name	01	<u>String</u>	inherited from: IdentifiedObject

322 Table 6 shows all association ends of Fault with other classes.

323

Table 6 – Association ends of GridDisturbanceProfile::Fault with other classes

mult from	name	mult to	type	description
1*	GridDisturbance	01	<u>GridDisturbance</u>	(NC) A grid disturbance to contain all faults.
0*	SystemOperator	01	<u>SystemOperator</u>	(NC) The system operator in whose control area this fault occurred.
0*	BaseVoltage	01	BaseVoltage	(NC) The base voltage of this fault.
01	FaultyEquipment	11	<u>Equipment</u>	Equipment carrying this fault.
0*	Location	11	Location	Location of this fault.

324

325 3.7 (NC) FaultCause root class

- 326 Fault cause.
- 327 Table 7 shows all attributes of FaultCause.



328 Table 7 – Attributes of GridDisturbanceProfile::FaultCause

name	mult	type	description
certaintyLevel	11	CertaintyLevelKind	(NC) The degree of certainty of which the cause of a fault is determined by a user.
			Note 1: the used certainty levels are low, medium and high. High certainty level is used when the cause of a fault is 100 % certain or when the cause is the most probable cause and potentially determined by an expert. Medium certainty level is used when the cause of the fault is very probable but there is not enough evidence to fully support the claim. Low certainty level is used when there is some idea of what the cause could be with the help of, for example, the fault details or expert knowledge.
			Note 2: the fault cause 'unknown' is used if no other fault cause can be chosen by any degree of certainty.
mRID	11	<u>String</u>	(NC) Master resource identifier issued by a model authority. The mRID is unique within an exchange context. Global uniqueness is easily achieved by using a UUID, as specified in RFC 4122, for the mRID. The use of UUID is strongly recommended.
			For CIMXML data files in RDF syntax conforming to IEC 61970-552, the mRID is mapped to rdf:ID or rdf:about attributes that identify CIM object elements.

329

330 Table 8 shows all association ends of FaultCause with other classes.

331 Table 8 – Association ends of GridDisturbanceProfile::FaultCause with other classes

mult from	name	mult to	type	description
1*	Fault	11	Fault	(NC) The fault defined for this fault and cause combination.
0*	FaultCauseType	11	FaultCauseType	(NC) The fault and cause combination to be simulated for this cause.

332

333 3.8 FaultCauseType

- 334 Inheritance path = <u>IdentifiedObject</u>
- 335 Type of cause of the fault.

336 Table 9 shows all attributes of FaultCauseType.

337

Table 9 – Attributes of GridDisturbanceProfile::FaultCauseType

name	mult	type	description
description	01	<u>String</u>	inherited from: IdentifiedObject
mRID	11	<u>String</u>	inherited from: IdentifiedObject
name	01	<u>String</u>	inherited from: IdentifiedObject

338

339 3.9 (NC) FaultOutage root class

- 340 Association class for relating one fault and one outage.
- Table 10 shows all attributes of FaultOutage.



Table 10 – Attributes of GridDisturbanceProfile::FaultOutage

name	mult	type	description
isMainFault	01	<u>Boolean</u>	(NC) If true the fault outage is the main fault.
mRID	11	String	(NC) Master resource identifier issued by a model authority. The mRID is unique within an exchange context. Global uniqueness is easily achieved by using a UUID, as specified in RFC 4122, for the mRID. The use of UUID is strongly recommended.
			For CIMXML data files in RDF syntax conforming to IEC 61970-552, the mRID is mapped to rdf:ID or rdf:about attributes that identify CIM object elements.

343

Table 11 shows all association ends of FaultOutage with other classes.

345 Table 11 – Association ends of GridDisturbanceProfile::FaultOutage with other classes

mult from	name	mult to	type	description
0*	Fault	11	<u>Fault</u>	(NC) The fault defined for this combination of a fault and an outage.
0*	Outage	11	<u>Outage</u>	(NC) The outage defined for this combination of a fault and an outage.

346

347 3.10 (NC) GridDisturbance

- 348 Inheritance path = <u>IdentifiedObject</u>
- Automatic, unintended, or manual undeferrable switching of breakers as a result of faults in the power grid.
- 351 Table 12 shows all attributes of GridDisturbance.

352

Table 12 – Attributes of GridDisturbanceProfile::GridDisturbance

name	mult	type	description
description	01	<u>String</u>	inherited from: IdentifiedObject
mRID	11	<u>String</u>	inherited from: IdentifiedObject
name	01	<u>String</u>	inherited from: IdentifiedObject

353

354 **3.11 (abstract) IdentifiedObject root class**

- 355 This is a root class to provide common identification for all classes needing identification and
- 356 naming attributes.
- 357 Table 13 shows all attributes of IdentifiedObject.

358

Table 13 – Attributes of GridDisturbanceProfile::IdentifiedObject

name	mult	type	description
description	01	<u>String</u>	The description is a free human readable text describing or naming the object. It may be non unique and may not correlate to a naming hierarchy.
mRID	11	<u>String</u>	Master resource identifier issued by a model authority. The mRID is unique within an exchange context. Global uniqueness is easily achieved by using a UUID, as specified in RFC 4122, for the mRID. The use of UUID is strongly recommended.



name	mult	type	description
			For CIMXML data files in RDF syntax conforming to IEC 61970-552, the mRID is mapped to rdf:ID or rdf:about attributes that identify CIM object elements.
name	01	String	The name is any free human readable and possibly non unique text naming the object.

360 3.12 (NC) Interruption

- 361 Inheritance path = IdentifiedObject
- 362 Disappearance of the supply voltage at a delivery point.
- 363 Table 14 shows all attributes of Interruption.
- 364

Table 14 – Attributes of GridDisturbanceProfile::Interruption

name	mult	type	description
startDateTime	11	<u>DateTime</u>	(NC) The date and time at which the interruption occurred.
duration	11	Duration	(NC) The duration of the interruption.
energyNotDelivered	01	<u>RealEnergy</u>	(NC) The estimated energy which would have been delivered through the delivery point if no interruption and no transmission restrictions had occurred.
energyNotSupplied	01	<u>RealEnergy</u>	(NC) The estimated energy which would have been supplied to end-users if no interruption and no transmission restrictions had occurred.
interruptedPower	11	<u>ActivePower</u>	(NC) The estimated power that was delivered through the delivery point when the interruption occurred.
description	01	<u>String</u>	inherited from: IdentifiedObject
mRID	11	<u>String</u>	inherited from: IdentifiedObject
name	01	String	inherited from: IdentifiedObject

365

366 Table 15 shows all association ends of Interruption with other classes.

367 Table 15 – Association ends of GridDisturbanceProfile::Interruption with other classes

mult from	name	mult to	type	description
01	InterruptedDeliveryEquip ment	11	<u>Equipment</u>	(NC) The delivery point (equipment) that is affected by the interruption. It is an equipment, power transformer or busbar in the grid where electricity is exchanged.
0*	Outage	01	Outage	(NC) One outage may have multiple interruptions.

368

369 3.13 Location

- 370 Inheritance path = <u>IdentifiedObject</u>
- 371 The place, scene, or point of something where someone or something has been, is, and/or will
- be at a given moment in time. It can be defined with one or more position points (coordinates)in a given coordinate system.
- Table 16 shows all attributes of Location.



Table 16 – Attributes of GridDisturbanceProfile::Location

name	mult	type	description
description	01	<u>String</u>	inherited from: IdentifiedObject
mRID	11	<u>String</u>	inherited from: IdentifiedObject
name	01	<u>String</u>	inherited from: IdentifiedObject

376

375

377 378

Table 17 shows all association ends of Location with other classes.

Table 17 – Association ends of GridDisturbanceProfile::Location with other classes

mult from	name	mult to	type	description
0*	CoordinateSystem	11	<u>CoordinateSystem</u>	Coordinate system used to describe position points of this location.

379

380 3.14 (abstract) Outage

- 381 Inheritance path = <u>Document</u> : <u>IdentifiedObject</u>
- 382 Document describing details of an active or planned outage in a part of the electrical network. 383 A non-planned outage may be created upon:
- 384 - a breaker trip,
- 385 - a fault indicator status change,
- 386 - a meter event indicating customer outage,
- a reception of one or more customer trouble calls, or 387
- an operator command, reflecting information obtained from the field crew. 388
- 389 Outage restoration may be performed using a switching plan which complements the outage
- 390 information with detailed switching activities, including the relationship to the crew and work.
- 391 A planned outage may be created upon:
- 392 - a request for service, maintenance or construction work in the field, or
- an operator-defined outage for what-if/contingency network analysis. 393
- 394 Table 18 shows all attributes of Outage.
- 395

Table 18 – Attributes of GridDisturbanceProfile::Outage

name	mult	type	description
description	01	<u>String</u>	inherited from: IdentifiedObject
mRID	11	<u>String</u>	inherited from: IdentifiedObject
name	01	<u>String</u>	inherited from: IdentifiedObject

396 397

398

Table 19 shows all association ends of Outage with other classes.

Table 19 – Association ends of GridDisturbanceProfile::Outage with other classes

mult from	name	mult to	type	description
01	Equipments	11	<u>Equipment</u>	All equipments associated with this outage.

399

400 3.15 PositionPoint root class

401 Set of spatial coordinates that determine a point, defined in the coordinate system specified in 402 'Location.CoordinateSystem'. Use a single position point instance to describe a point-oriented 403 location. Use a sequence of position points to describe a line-oriented object (physical location 404 of non-point oriented objects like cables or lines), or area of an object (like a substation or a 405 geographical zone - in this case, have first and last position point with the same values).



406 Table 20 shows all attributes of PositionPoint.

407

Table 20 – Attributes of GridDisturbanceProfile::PositionPoint

name	mult	type	description
xPosition	11	<u>String</u>	X axis position.
yPosition	11	<u>String</u>	Y axis position.
zPosition	01	<u>String</u>	(if applicable) Z axis position.

408

409 Table 21 shows all association ends of PositionPoint with other classes.

410

411

Table 21 – Association ends of GridDisturbanceProfile::PositionPoint with other classes

mult from	name	mult to	type	description
1*	Location	11	Location	Location described by this position point.

412

413 **3.16 (abstract,NC) SystemOperator root class**

414 System operator.

415 3.17 UnplannedOutage

- 416 Inheritance path = <u>Outage</u> : <u>Document</u> : <u>IdentifiedObject</u>
- 417 Document describing the consequence of an unplanned outage in a part of the electrical
 418 network. For the purposes of this model, an unplanned outage refers to a state where energy
 419 is not delivered; such as, customers out of service, a street light is not served, etc.
- 420 A unplanned outage may be created upon:
- 421 impacts the SAIDI calculation
- 422 a breaker trip,
- 423 a fault indicator status change,
- 424 a meter event indicating customer outage,
- 425 a reception of one or more customer trouble calls, or
- 426 an operator command, reflecting information obtained from the field crew.
- 427 Outage restoration may be performed using a switching plan which complements the outage
- 428 information with detailed switching activities, including the relationship to the crew and work.
- 429 Table 22 shows all attributes of UnplannedOutage.
- 430

Table 22 – Attributes of GridDisturbanceProfile::UnplannedOutage

name	mult	type	description
startDateTime	01	<u>DateTime</u>	(NC) The date and time at which the unplanned outage occurred.
duration	11	<u>Duration</u>	(NC) The duration of the unplanned outage.
tripKind	11	TripKind	 (NC) Whether the type of the trip due to the outage was automatic, automatic with successful automatic reclosing or manual. In case of a fault in the reclosing automatics resulting in lack of reclosing, automatic should be chosen as an alternative.
autoReclosingKind	11	AutoReclosingKind	 (NC) The type of autoreclosing that occurred with the trip. If high-speed automatic reclosing is successful at one end of a line, but the line needs to be reclosed manually at the other end, choose manual reclosing.



name	mult	type	description
			In this document, high-speed automatic reclosing refers to automatic reclosing after less than 2 seconds.
systemUnitKind	11	SystemUnitKind	(NC) The type of system unit of the component affected by the outage.
			A system unit is defined as:
			A group of components which are delimited by one or more circuit breakers.
			Note 1: the system unit concept has been defined to simplify the calculation of availability. While a system unit is always delimited by circuit breakers, an individual component may not always be. A system unit may therefore contain more than one component.
			Note 2: the circuit breakers are not included in the system unit.
			Note 3: a tripped element is synonymous to a tripped system unit.
			Note 4: the type of a system unit is determined by its dominant component. The available system unit types are power transformer, overhead line, cable, reactor, busbar, series capacitor, shunt capacitor and SVC.
			Note 5: when a system unit is no longer transporting or supplying electrical energy, the system unit is affected by an outage. The system unit is unavailable after the outage has occurred.
reportedStartTime	01	DateTime	The earliest start time of the Outage - as reported by some system or individual
description	01	<u>String</u>	inherited from: IdentifiedObject
mRID	11	<u>String</u>	inherited from: IdentifiedObject
name	01	<u>String</u>	inherited from: IdentifiedObject

Table 23 shows all association ends of UnplannedOutage with other classes.

433

434

Table 23 – Association ends of GridDisturbanceProfile::UnplannedOutage with other classes

mult from	name	mult to	type	description
01	Equipments	11	<u>Equipment</u>	inherited from: Outage

435

436 **3.18 (NC) AutoReclosingKind enumeration**

- 437 The type of autoreclosing that occurred with the trip.
- 438 If high-speed automatic reclosing is successful at one end of a line, but the line needs to be 439 reclosed manually at the other end, choose manual reclosing.
- 440 In this document, high-speed automatic reclosing refers to automatic reclosing after less than441 2 seconds.
- 442 Table 24 shows all literals of AutoReclosingKind.

443

Table 24 – Literals of GridDisturbanceProfile::AutoReclosingKind

literal	value	description
automaticallyAfterLessThan2Seconds		If the automatic reclosing was successful in 2 seconds or less.
		Also known as "successful high-speed reclosing".



literal	value	description
automaticallyAfter2SecondsOrMore		If the automatic reclosing was successful in 2 seconds or more.
		Also known as "successful high-speed reclosing".
manuallyAfterRestructuringOfOperations		If the reclosing was done manually after restructuring of operations.
manuallyAfterInspection		If the reclosing was done manually after inspection of the component.
manuallyWithoutEitherInspectionRepairOrRestru cturingOfOperations		If the reclosing was done manually without any inspections, repairs or restructurings of operations.
unknown		If the type of auto-reclosing is unknown.
other		If the type of auto-reclosing is not unknown but does not fit the other categories, report it as other.
manuallyAfterRepair		If the reclosing was done manually after repair.

445 **3.19 (NC) CertaintyLevelKind enumeration**

- High certainty level is used when the cause of a fault is 100 % certain or when the cause is the
- 447 most probable cause and potentially determined by an expert.
- 448 Table 25 shows all literals of CertaintyLevelKind.
- 449

Table 25 – Literals of GridDisturbanceProfile::CertaintyLevelKind

	literal	value	description
ł	high		The certainty level is high.
r	medium		The certainty level is medium.
I	low		The certainty level is low.
r	none		The certainty level is none.

450

451 3.20 (NC) FaultCategoryKind enumeration

- 452 The available kinds of fault categories.
- 453 Table 26 shows all literals of FaultCategoryKind.
- 454

Table 26 – Literals of GridDisturbanceProfile::FaultCategoryKind

literal	value	description
technical		A fault due to a technical error.
operational		A fault due to a temporary human error. Note 1: incorrect operation is considered a fault in a component, or in other words, the incorrect operation is attributed to the unit which has been operated incorrectly.
system		A fault due to off-nominal parameters, exceeding of regulated norms and standards, or exceeding protection limits. Note 1: Typical examples of system fault causes are high/low frequency, power oscillations, overload, overvoltage, undervoltage or high harmonic content in voltage or current. Common causes for system faults are significant changes in load or generation and switching of lines or transformers with following change of load flow.



456 **3.21 (NC) FaultKind enumeration**

457 One fault can consist of several fault types. If a fault consists of several fault types, the most 458 significant fault type is used.

In case of developing faults, that is in faults changing from one type to another, the final typeis given.

461 Table 27 shows all literals of FaultKind.

462

Table 27 – Literals of GridDisturbanceProfile::FaultKind

literal	value	description
functional		The components main function failed to occur.
undesiredFunction		If the component's main function occurred correctly but had an undesired result, that is, the fault. Is only stated if the component is a circuit breaker, disconnector or control system.
other		For example, geomagnetic currents, SSR, capacitor bank imbalances, bad contact, overheating.
lineToGround		The fault connects the indicated phases to ground. The line to line fault impedance is not used and assumed infinite. The full ground impedance is connected between each phase specified in the fault and ground, but not between the phases.
lineToLine		The fault connects the specified phases together without a connection to ground. The ground impedance of this fault is ignored. The line to line impedance is connected between each of the phases specified in the fault. For example three times for a three phase fault, one time for a two phase fault. A single phase fault should not be specified.
lineToLineToGround		The fault connects the indicated phases to ground and to each other. The line to line impedance is connected between each of the phases specified in the fault in a full mesh. For example three times for a three phase fault, one time for a two phase fault. A single phase fault should not be specified. The full ground impedance is connected between each phase specified in the fault and ground.
lineOpen		The fault is when the conductor path is broken between two terminals. Additional coexisting faults may be required if the broken conductor also causes connections to grounds or other lines or phases.

463

464 **3.22** PhaseConnectedFaultKind enumeration

- 465 The type of fault connection among phases.
- 466 Table 28 shows all literals of PhaseConnectedFaultKind.

467

Table 28 – Literals of GridDisturbanceProfile::PhaseConnectedFaultKind

literal	value	description
lineToGround		The fault connects the indicated phases to ground. The line to line fault impedance is not used and assumed infinite. The full ground impedance is connected between each phase



literal	value	description
		specified in the fault and ground, but not between the phases.
lineToLine		The fault connects the specified phases together without a connection to ground. The ground impedance of this fault is ignored. The line to line impedance is connected between each of the phases specified in the fault. For example three times for a three phase fault, one time for a two phase fault. A single phase fault should not be specified.
lineToLineToGround		The fault connects the indicated phases to ground and to each other. The line to line impedance is connected between each of the phases specified in the fault in a full mesh. For example three times for a three phase fault, one time for a two phase fault. A single phase fault should not be specified. The full ground impedance is connected between each phase specified in the fault and ground.
lineOpen		The fault is when the conductor path is broken between two terminals. Additional coexisting faults may be required if the broken conductor also causes connections to grounds or other lines or phases.

469 **3.23 PhaseCode enumeration**

An unordered enumeration of phase identifiers. Allows designation of phases for both
transmission and distribution equipment, circuits and loads. The enumeration, by itself, does
not describe how the phases are connected together or connected to ground. Ground is not
explicitly denoted as a phase.

Residential and small commercial loads are often served from single-phase, or split-phase, secondary circuits. For the example of s12N, phases 1 and 2 refer to hot wires that are 180 degrees out of phase, while N refers to the neutral wire. Through single-phase transformer connections, these secondary circuits may be served from one or two of the primary phases A, B, and C. For three-phase loads, use the A, B, C phase codes instead of s12N.

479 The integer values are from IEC 61968-9 to support revenue metering applications.

480 Table 29 shows all literals of PhaseCode.

481

Table 29 – Literals of GridDisturbanceProfile::PhaseCode

literal	value	description
ABCN	225	Phases A, B, C, and N.
ABC	224	Phases A, B, and C.
ABN	193	Phases A, B, and neutral.
ACN	41	Phases A, C and neutral.
BCN	97	Phases B, C, and neutral.
АВ	132	Phases A and B.
AC	96	Phases A and C.
BC	66	Phases B and C.
AN	129	Phases A and neutral.
BN	65	Phases B and neutral.
CN	33	Phases C and neutral.
A	128	Phase A.



literal	value	description
В	64	Phase B.
С	32	Phase C.
Ν	16	Neutral phase.
s1N	528	Secondary phase 1 and neutral.
s2N	272	Secondary phase 2 and neutral.
s12N	784	Secondary phases 1, 2, and neutral.
s1	512	Secondary phase 1.
s2	256	Secondary phase 2.
s12	768	Secondary phase 1 and 2.
none	0	No phases specified.
Х	1024	Unknown non-neutral phase.
XY	3072	Two unknown non-neutral phases.
XN	1040	Unknown non-neutral phase plus neutral.
XYN	3088	Two unknown non-neutral phases plus neutral.

483 3.24 (NC) SystemUnitKind enumeration

- 484 A system unit is defined as:
- 485 A group of components which are delimited by one or more circuit breakers.

Note 1: the system unit concept has been defined to simplify the calculation of availability. While 486

a system unit is always delimited by circuit breakers, an individual component may not always 487 be. A system unit may therefore contain more than one component. 488

- Note 2: the circuit breakers are not included in the system unit. 489
- Note 3: a tripped element is synonymous to a tripped system unit. 490
- 491

Note 4: the type of a system unit is determined by its dominant component. The available system 492 unit types are power transformer, overhead line, cable, reactor, busbar, series capacitor, shunt 493 capacitor and SVC.

- 494 Note 5: when a system unit is no longer transporting or supplying electrical energy, the system
- 495 unit is affected by an outage. The system unit is unavailable after the outage has occurred.
- Table 30 shows all literals of SystemUnitKind. 496
- 497

Table 30 – Literals of GridDisturbanceProfile::SystemUnitKind

literal	value	description
cable		If the main function of the system unit is cable.
overheadLine		If the main function of the system unit is overhead line.
powerTransformer		If the main function of the system unit is power transformer.
reactor		If the main function of the system unit is reactor.
busbar		If the main function of the system unit is busbar.
seriesCapacitor		If the main function of the system unit is series capacitor.
shuntCapacitor		If the main function of the system unit is shunt capacitor.
SVC		If the main function of the system unit is static var compensator (SVC).
other		If it is of other kind.
facts		If the main function of the system unit is FACTS.



literal	value	description
dcConverter		If the main function of the system unit is DCConverter.
dcCable		If the main function of the system unit is DCCable.

499 **3.25 (NC) TripKind enumeration**

- 500 Whether the type of the trip due to the outage was automatic, automatic with successful automatic reclosing or manual.
- 502 In case of a fault in the reclosing automatics resulting in lack of reclosing, automatic should be 503 chosen as an alternative.
- 504 Table 31 shows all literals of TripKind.

505

Table 31 – Literals of GridDisturbanceProfile::TripKind

literal	value	description
automatic		The trip that resulted in the outage was automatic.
		In case of a fault in the reclosing automatics resulting in lack of reclosing, automatic should be chosen as an alternative.
automaticWithUnsuccessfulAutomaticReclosing		The trip that resulted in an outage was correctly initiated but the automatic reclosing was unsuccessful.
		In case of a fault in the reclosing automatics resulting in lack of reclosing, automatic should be chosen as an alternative.
manual		The trip that resulted in the outage was manually cleared.

506

507 **3.26 UnitMultiplier enumeration**

508 The unit multipliers defined for the CIM. When applied to unit symbols, the unit symbol is 509 treated as a derived unit. Regardless of the contents of the unit symbol text, the unit symbol 510 shall be treated as if it were a single-character unit symbol. Unit symbols should not contain 511 multipliers, and it should be left to the multiplier to define the multiple for an entire data type.

For example, if a unit symbol is "m2Pers" and the multiplier is "k", then the value is $k(m^{**}2/s)$, and the multiplier applies to the entire final value, not to any individual part of the value. This can be conceptualized by substituting a derived unit symbol for the unit type. If one imagines that the symbol "P" represents the derived unit "m2Pers", then applying the multiplier "k" can be conceptualized simply as "kP".

For example, the SI unit for mass is "kg" and not "g". If the unit symbol is defined as "kg", then 517 the multiplier is applied to "kg" as a whole and does not replace the "k" in front of the "g". In 518 519 this case, the multiplier of "m" would be used with the unit symbol of "kg" to represent one gram. As a text string, this violates the instructions in IEC 80000-1. However, because the unit symbol 520 in CIM is treated as a derived unit instead of as an SI unit, it makes more sense to conceptualize 521 the "kg" as if it were replaced by one of the proposed replacements for the SI mass symbol. If 522 one imagines that the "kg" were replaced by a symbol "b", then it is easier to conceptualize the 523 multiplier "m" as creating the proper unit "mp", and not the forbidden unit "mkg". 524 Table 32 shows all literals of UnitMultiplier. 525

526

literal	value	description
k	3	Kilo 10**3.
Μ	6	Mega 10**6.



528 3.27 UnitSymbol enumeration

The derived units defined for usage in the CIM. In some cases, the derived unit is equal to an 529 SI unit. Whenever possible, the standard derived symbol is used instead of the formula for the 530 531 derived unit. For example, the unit symbol Farad is defined as "F" instead of "CPerV". In cases where a standard symbol does not exist for a derived unit, the formula for the unit is used as 532 the unit symbol. For example, density does not have a standard symbol and so it is represented 533 as "kgPerm3". With the exception of the "kg", which is an SI unit, the unit symbols do not contain 534 multipliers and therefore represent the base derived unit to which a multiplier can be applied as 535 536 a whole.

537 Every unit symbol is treated as an unparseable text as if it were a single-letter symbol. The 538 meaning of each unit symbol is defined by the accompanying descriptive text and not by the 539 text contents of the unit symbol.

To allow the widest possible range of serializations without requiring special character handling, several substitutions are made which deviate from the format described in IEC 80000-1. The division symbol "/" is replaced by the letters "Per". Exponents are written in plain text after the unit as "m3" instead of being formatted as "m" with a superscript of 3 or introducing a symbol several substitutions are made which deviate from the letters "deg". Any clarification of the

545 meaning for a substitution is included in the description for the unit symbol.

546 Non-SI units are included in list of unit symbols to allow sources of data to be correctly labelled 547 with their non-SI units (for example, a GPS sensor that is reporting numbers that represent feet 548 instead of meters). This allows software to use the unit symbol information correctly convert 549 and scale the raw data of those sources into SI-based units.

- 550 The integer values are used for harmonization with IEC 61850.
- 551 Table 33 shows all literals of UnitSymbol.

552

Table 33 – Literals of GridDisturbanceProfile::UnitSymbol

literal	value	description
W	38	Real power in watts (J/s). Electrical power may have real and reactive components. The real portion of electrical power (I ² R or VIcos(phi)), is expressed in Watts. See also apparent power and reactive power.
Wh	72	Real energy in watt hours.

553

554 3.28 ActivePower datatype

555 Product of RMS value of the voltage and the RMS value of the in-phase component of the 556 current.

557 Table 34 shows all attributes of ActivePower.

558

Table 34 – Attributes of GridDisturbanceProfile::ActivePower

name	mult	type	description
multiplier	01	<u>UnitMultiplier</u>	(const=M)
unit	01	<u>UnitSymbol</u>	(const=W)
value	01	<u>Float</u>	

559

560 3.29 RealEnergy datatype

561 Real electrical energy.

562 Table 35 shows all attributes of RealEnergy.



Table 35 – Attributes of GridDisturbanceProfile::RealEnergy

name	mult	type	description
multiplier	01	<u>UnitMultiplier</u>	
unit	01	<u>UnitSymbol</u>	(const=Wh)
value	01	<u>Float</u>	

564

565 **3.30 Boolean primitive**

566 A type with the value space "true" and "false".

567 3.31 DateTime primitive

568 Date and time as "yyyy-mm-ddThh:mm:ss.sss", which conforms with ISO 8601. UTC time zone 569 is specified as "yyyy-mm-ddThh:mm:ss.sssZ". A local timezone relative UTC is specified as 570 "yyyy-mm-ddThh:mm:ss.sss-hh:mm". The second component (shown here as "ss.sss") could 571 have any number of digits in its fractional part to allow any kind of precision beyond seconds.

572 3.32 Duration primitive

573 Duration as "PnYnMnDTnHnMnS" which conforms to ISO 8601, where nY expresses a number 574 of years, nM a number of months, nD a number of days. The letter T separates the date 575 expression from the time expression and, after it, nH identifies a number of hours, nM a number 576 of minutes and nS a number of seconds. The number of seconds could be expressed as a 577 decimal number, but all other numbers are integers.

578 3.33 Integer primitive

579 An integer number. The range is unspecified and not limited.

580 3.34 Float primitive

581 A floating point number. The range is unspecified and not limited.

582 3.35 String primitive

- 583 A string consisting of a sequence of characters. The character encoding is UTF-8. The string 584 length is unspecified and unlimited.
- 585

586